



Self-adhesive Wall Panels

Installation Guide

1



Prepare the Wall and Panels

Clean and Measure: Ensure the wall surface is clean, dry, and free of any debris. Measure the wall area to determine how many Panels are needed and mark the placement of each panel.

Cut Panels (if necessary): To fit wall dimensions, the end panels might need to be cut. Use sharp scissors to cut the panels to size. It is recommended that cut panels are placed near the top of the ceiling.

2



Peel off the Backing and Stick

Peel Off the Backing: Starting at one corner of each panel, peel off the protective backing to expose the adhesive.

Position and Stick the Panel: Carefully position the panel on the wall, aligning it with position marks. Press firmly from the center outward to ensure the adhesive bonds well to the wall surface and to remove any air bubbles.

3



Repeat for all Panels and Finish

Press Firmly: After placing each panel, press firmly along all edges and across the surface to ensure a strong bond.

Repeat and Finish: Continue the process with the remaining panels, ensuring each one aligns properly with the previous panels. Once all panels are installed, inspect for any areas that may need additional pressing to secure the adhesive.