

### Tools Needed



Level



Tape measure



Utility knife



Construction glue



Tape



Pencil

### Step 1: Prepare the Surface

1. Remove furniture and any wall decorations.
2. Clean the wall to remove dust, grease, or debris.
3. Fill any holes or cracks in the wall.
4. Ensure the wall is dry and even.



### Step 2: Measure and Cut

5. Measure the wall and mark the starting point for the first panel.
6. Use a level to ensure straight alignment.
7. Cut panels to size if necessary using a utility knife or fine-tooth saw.

\*For outdoor installation, brush 2 coats of water based varnish

### Step 3: Apply Adhesive and Install Panels

8. Apply construction adhesive to the back of the panel.
9. Press the panel firmly onto the marked spot on the wall. Hold for a few seconds to secure the bond. Repeat the process, aligning each panel carefully with the previous one. Continue until all surface area is covered.

