



Tools Needed:

1. Level
2. Measuring Tape
3. Scissors or Utility Knife

Optional:

1. Painter's tape
2. Plastic Smoother or Squeegee




Step 1: Prepare the Wall

- Make sure the wall is clean, dry, and smooth
- Repair any cracks or holes and lightly sand if needed
- Wipe dust off with a clean cloth
- **Use a level to draw one straight vertical guide line from ceiling to floor for your first strip**

Step 2: Measure & Cut

- Measure the height of your wall and **add 1–2 inches** for trimming
- Roll out the wallpaper and cut your strips with scissors or utility knife





Step 3: Apply the Wallpaper

- Peel back **6–12 inches** of the backing from the top
- Align the top edge with the ceiling and side to your vertical guide line
- Lightly press the top into place
- Slowly peel the backing downward while smoothing from the **center outward**
- Do **not stretch** the wallpaper

Tip: Use painter's tape to hold the strip in place before peeling for easier alignment.

Step 4: Finish & Trim

- Apply remaining strips, aligning the start points and following the vertical guideline
- Trim excess at the ceiling, baseboard, and corners with a sharp knife
- For air bubbles:
 - Gently lift and reapply the section, or
 - Use light heat from a hairdryer and smooth outward

